

Table of Contents

Introduction and Definitions	1
Objective of this Textbook	1
Textbook Outline	2
Textbook Conventions	3
Introduction to Pro/INTRALINK	4
Definitions	5
Capabilities of Pro/INTRALINK	7
Pro/INTRALINK and Pro/ENGINEER Object Reference	8
Pro/INTRALINK System Architecture	9
Intralink Administration Usernames and Passwords	10
Data Server Information	11
Multi-Server Configuration	12
Components of the Pro/INTRALINK Client	13
The Intralink Client Menu	13
Intralink Objects	14
Login / Logout	15
The Commonsplace	16
The Workspace	17
Linked Session of Pro/ENGINEER	17
Locating Objects	18
Preferences and Defaults	18
Administration Tasks	18
Purge	18
RTP Forms	18
Intralink Object Attributes	19
Installing the Server Software	22
Prepare for the Installation	22
Installing the File Server	23
Define the Installation Directory	24
Initiate the File Server Installation	25
Start the Intralink File Server Service	26
Installing the Data Server	27
Define the Database Size and Location	28
Specify the File Vault Information	29
Optional Installation Steps	30
Define the Oracle System Administrator Password	31
Define the Server Type	32
Initiate the Data Server Installation	33
Installation Progress Report	34
Installation Issues	35
Complete the Installation	36
Installing the Client Software	37
Introduction	37
Define the Installation Directory	38
Define the Data Server	39

Specify the License Server	40
Configure the Startup Command	41
Optional Installation Steps	42
Set the Windows Preferences	43
Define the Help Files Location and Browser	44
Initiate the Installation	45
Complete the Installation	46
Data Server Management Utility	47
Introduction	47
The Data Server Management Utility Menu	48
Starting the Data Server	49
Starting the Data Server (continued)	50
Login to the Data Server	51
Login to the File Server	52
Resize the Database	53
Export the Data Server Metadata	54
Importing an Oracle Dump File	55
DSMU Reports	56
Creating Additional File Servers	58
Creating Additional File Vaults	59
Moving a File Vault	60
Moving a File Vault (continued)	61
Removing File Vaults	62
Removing File Servers	63
Database Backup Utility	64
Print the DSMU Window	65
Intralink Client Administration	66
Introduction	66
Administration Categories	67
Administration Categories (continued)	68
File Vaults and Storage Clusters	69
Introduction	69
File Vaults	70
Storage Clusters	71
Adding File Vaults to Storage Clusters	72
Users and Groups	73
Introduction	73
Adding Users	74
User Passwords and Email Addresses	75
Creating Groups	76
Users and Groups	77
Administration Authorization	78
Exercise 1 – Create Users and Groups	79
Roles	88
Introduction	88
Default Roles	89
Role Action Descriptions	90
Object Actions	91
Folder Actions	92
Creating a New Role	93
Exercise 2 – Roles	94

Revision Sequence	98
Introduction.....	98
Exporting Revision Sequences	99
Importing Revision Sequences	100
Exercise 3 – Creating a Revision Sequence.....	101
Release Schemes and Levels	104
Introduction.....	104
Creating a New Release Scheme	105
Creating Release Levels	106
Changing a Release Scheme	107
Exercise 4 – Creating a Release Scheme	108
Release Procedures	112
Introduction.....	112
Creating a New Release Procedure.....	113
Adding Voters.....	114
Notification and Distribution Lists	115
Email Server Setup	116
Exercise 5 – Creating a Release Procedure.....	117
Folders	125
Introduction.....	125
The Commonsplace Folder Structure	126
Creating Folders.....	127
Folder Authorizations	128
The Folder Authorization Table.....	129
Setting Folder Authorizations	130
Setting Folder Authorizations (continued).....	131
Assigning Release Procedures	132
Folder Attributes	133
Folder Replication	134
Modifying a Folder.....	135
Moving a Folder.....	136
Exercise 6 – Folders	137
History Tracks	144
Introduction.....	144
Creating History Tracks.....	145
Disabling History Tracks	146
Deleting History Tracks.....	147
Triggers	148
Introduction.....	148
Facts About Triggers.....	149
Trigger Examples	149
Trigger Definition	150
Registering a Trigger.....	151
Deactivating a Trigger	152
Deleting a Trigger.....	152
Object Types	153
Introduction.....	153
Defining an Object Type.....	154
Application Startup Command Syntax	155
Keyword Descriptions	156
Deleting an Object Type.....	157

Dependency Configuration	158
Introduction.....	158
Default Dependency Configurations	159
Dependency Configuration Files	159
Dependency Configuration Rule Syntax	160
Importing Dependency Configuration Files	162
Exporting Dependency Configuration Files	163
Intralink Attributes	164
Introduction.....	164
Attribute Types	165
Object Attributes.....	166
Creating Object Attributes	167
Attribute Authorization.....	168
Creating Folder Attributes	169
Creating User Attributes.....	170
Modifying Attributes.....	171
Deleting Attributes	172
Indexing Attributes.....	173
Exercise 7 – Creating Attributes.....	174
System-Wide Preferences	177
Introduction.....	177
Check In Preferences.....	178
Check In Preferences (continued).....	179
Checkout Preferences.....	180
Checkout Preferences (continued).....	181
Promote/Demote Preferences.....	182
Configuration Preferences	183
Application Behavior Preferences	184
Replicas Preferences	186
Parts Link Preferences.....	187
Exercise 8 – System-Wide Preferences.....	188
Locate Objects	194
Introduction.....	194
The Locate Browser Window	195
The Locate Browser Window (continued).....	169
Searching for Objects.....	197
Saving Searches	199
Using a Saved Search to find Objects	200
Redefining a Saved Search	200
Deleting a Saved Search	200
Using Search Results.....	201
Exercise 9 – Locate Objects	202
Purge Objects	207
Introduction.....	207
Defining the Purge Criteria	208
Defining the Purge Criteria (continued).....	209
Saving Purge Criteria	201
Verify the Purge Criteria.....	211
Purge Conflicts.....	212
Execute the Purge.....	212

Storage Cluster Replication	213
Introduction.....	213
Multi-Site Setup	214
Replicating a Storage Cluster	215
Replicating a Storage Cluster (continued)	216
Replication Preferences	217
Updating a Replicated Storage Cluster.....	217
Using a Command Line for Replication Tasks.....	218
Package Replication	219
Introduction.....	219
Identifying the Source and Target Data Servers.....	220
Enable Package Replication	221
Replication Preferences	225
Distribution Roles	226
Assigning Distribution Roles	227
Creating a Package.....	228
Creating a Package (continued).....	229
Publishing a Package.....	230
Publishing a Package (continued).....	231
Subscribing to a Package	232
Subscription Conflicts.....	232
Rejecting a Package	233
Deleting a Package	233
Maintaining Package Replication	234
Using the Registry	235
Using the Registry (continued).....	236
Using the Registry (continued).....	237
About the Author	238

Pro/INTRALINK 3.3 Administration Guide